



Repairing Broken or Damaged Concrete using Fast Setting Cement Patcher

Project how-to guide

PREPARATION



Mix product according to package instructions.

Wet the area to be repaired. This will prevent the concrete from absorbing the water from the Fast Setting Cement Patcher.



APPLICATION



Mix the material to a wet consistency (slurry coat). This will help the product bond to the existing concrete.



Place some of the material, by hand, on the damaged area.

**** BE SURE TO WEAR GLOVES ****



Repairing Broken or Damaged Concrete using Fast Setting Cement Patcher

Project how-to guide



Add additional product to the mix to create a thicker consistency.

FINISHING



Place the material on the damaged area using a margin trowel. As it begins to stiffen, shape the material to form the corner.



Complete the repair by using a damp paintbrush to smooth any existing seams and blend the repaired area into the existing concrete.

NOTE: For complete product information, please refer to product data sheet.