



SETTING FENCE POSTS

using Fast Setting Concrete Mix

Project how-to guide

◆ The Pro's Choice Since 1936

PREPARATION



NO PREMIXING IS REQUIRED.

Dig a hole using a post-hole digger to 1/3 the length of the post and insert the post.



APPLICATION



Have someone hold the post and ensure it is level.



Pour the hole approximately 1/3 of the way full with water.




SETTING FENCE POSTS

using Fast Setting Concrete Mix

Project how-to guide

◆ The Pro's Choice Since 1936

FINISHING



Pour the product in the hole, ensuring the product is poured all the way around.



Add water as needed. No bracing is required. Sakrete Fast Setting Cement will set in approximately 30 minutes.

NOTE: For complete product information, please refer to product data sheet.