



Flo-Coat Resurfacer

Project how-to guide

MIXING



Follow mixing instructions on the package.

APPLICATION



Pour mixed product onto the concrete surface.



Using a squeegee, push or pull the material across the concrete surface to spread it evenly. Flo-Coat Resurfacer may be applied from feather edge to 1/2" in thickness.



Flo-Coat Resurfacer

Project how-to guide



Tap the squeegee periodically to remove excess material. Using an old towel, wipe the squeegee to remove all material prior to finishing.

FINISHING



Once the product has been applied smoothly and evenly over the entire surface, take a broom and add texture to the surface. This is to prevent the concrete from being slick when finished. Using a broom can also help remove any squeegee lines you may have created when applying the product.

NOTE: For complete product information, please refer to product data sheet.