



# Filling Joints Between Pavers

## using Paver Set

Project how-to guide

### PREPARATION



NO MIXING IS REQUIRED.

Remove sand to the full depth of the pavers. Be sure all weeds are removed.

NOTE: Product is suitable for new paver installations as well as existing installations.



### APPLICATION



Ensure that no pavers were dislodged during pressure washing. The wash the surface of the pavers with a cleaning solution.

Wait until the surface is completely dry before adding Paver Set (usually the next day).



Use a container, bag or funnel to pour the product into the paver joints. This will help reduce the risk of staining the pavers.



Tap on the pavers to consolidate the material into the joints.



# Filling Joints Between Pavers

## using Paver Set

Project how-to guide

### FINISHING



Once all Paver Set has been placed into the joints, use a broom to remove all excess product and prevent staining.



Product may also be removed using a leaf blower by placing the tip just above the pavers (preferred method instead of sweeping).

NOTE: This step is critical to avoid staining the pavers.



Gently mist the pavers using a wide, sweeping motion and avoid spraying directly into the joints. Spray for several minutes allowing the water to soak in. Repeat the process 3 or 4 times over a one-hour period.

Restrict access to the pavers for at least 24 hours.

NOTE: Do not allow the water to pool in the joints.

NOTE: For complete product information, please refer to product data sheet.