



# Asphalt Patch & Repair

using U.S. Cold Patch

Project how-to guide

## PREPARATION



NO MIXING IS REQUIRED.

Sweep and remove any loose material from the area to be patched.

NOTE: If product has hardened in bag, drop the bag and roll it to return it to a loose, potting-soil type consistency.



## APPLICATION



Pour the product from the bag and spread evenly in the hole in 1 to 2 inch layers.



Compact the material by tamping or driving over. U.S. Cold Patch cures by compaction, not evaporation.



NOTE: For complete product information, please refer to product data sheet.