

The Pro's Choice Since 1936

SAKRETE®

Concrete Mortar Dissolver

Sakrete® Concrete Mortar Dissolver is a safe, environmentally-friendly liquid alternative to aggressive acid concrete removers. Concrete Mortar Dissolver can be used to remove cured cement, concrete, mortar or stucco from most surfaces.

SAFETY:

READ and UNDERSTAND the Material Safety Data Sheet (MSDS) before using this product. WARNING: Wear protective clothing and equipment. For emergency information, call CHEMTREC at 800-424-9300 or 703-527-3887 (outside USA). KEEP OUT OF REACH OF CHILDREN.

DIRECTIONS FOR USE:

IMPORTANT: Never wet surface before applying this product.

- Completely saturate area of hardened concrete to be removed with undiluted Concrete Mortar Dissolver. Surface will turn white on contact, then darken. (If Concrete Mortar Dissolver evaporates, a white residue will appear. DO NOT RINSE! Re-apply Concrete Mortar Dissolver to reactivate as needed until concrete has softened to a mush).
- Allow Concrete Mortar Dissolver to penetrate 10-15 minutes. Then re-apply to same area. Keep surface wet with Concrete Mortar Dissolver. Concrete will begin to soften and release from surface. (Total time approximately 20-30 minutes)
- Rinse with cold water with a garden hose and pressure nozzle, or use a high-pressure washer. On extra thick build up, repeat cleaning directions until build up has softened.

Multiple applications used in conjunction with mechanical means may be necessary for removing stubborn or thick built up areas.

SHELF LIFE: One year from date of manufacture.

STORAGE:

Store in a tightly closed container off the floor in a dry place.

PACKAGING:

23 ounce: (680 ml)
5 Gallons (18.925 Liters)

FIRST AID:
EYES: All exposures are considered severe. Flush thoroughly in an eye wash for 15 minutes. Get medical attention immediately.
SKIN: Wash for 5 minutes
INHALATION: If excessive inhalation has occurred, initiate oxygen administration at a 2 to 6L per minute flow. Get medical attention immediately.
INGESTION: Do not induce vomiting. Conscious patient, give orally, high amounts of water or milk. Obtain medical attention immediately.

LIMITED PRODUCT WARRANTY

The manufacturer warrants that this product shall be of merchantable quality when used or applied in accordance with the manufacturer's instructions. This product is not warranted as suitable for any purpose other than the general purpose for which it is intended. This warranty runs for one (1) year from the date the product is purchased. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE DURATION OF THIS WARRANTY. Liability under this warranty is limited to replacement of defective product or, at the manufacturer's option, refund of the purchase price. CONSEQUENTIAL AND INCIDENTAL DAMAGES ARE NOT RECOVERABLE UNDER THIS WARRANTY.

Distributed by:
The SAKRETE Companies
866-SAKRETE
866-725-7383

REV 05-10